

Contents

Chapter 1	
Introduction	1-1
Chapter 2	
Tools and equipment	2-1
Chapter 3	
Carburetor fundamentals	3-1
Chapter 4	
Carburetor identification	4-1
Chapter 5	
Troubleshooting	5-1
Chapter 6	
Carburetor removal and installation	6-1
Chapter 7	
Overhaul and adjustments	
Part A	Overhaul tools and preparation
Part B	Four-barrel models: 4150, 4160, 4180, 4190; 4165,4175; 4500
	Three-barrel models: 3150, 3160
	Two-barrel models: 2300, 2305, 2380
Parte	Four-barrel models: 4010, 4011
Part D	Four-barrel model: 4360
	Two-barrel models: 2360, 6360
Part E	Two-barrel models: 5200, 5210, 5220; 6500,6510,6520
Part F	Two-barrel models: 2280, 6280
PartG	Two-barrel models: 2210, 2211,2245
PartH	Two-barrel models: 2100, 2110
Part I	One-barrel models: 1940,1945,1946, 1949; 6145, 6146, 6149
Part J	One-barrel models: 1920,1904,1908, 1960
Chapter 8	
Selection and modification	8-1
Chapter 9	
Reference and specifications	9-1
Glossary	GL-1
Index	IND-1